

Reusable Canisters

Canisters — Reusable polycarbonate canister/bracket assembly used to hold disposable liner.



Canister with Wall Mount

Bracket assembly has pre-attached tubing for connection to disposable liner. Wall to outer edge of canister is 8.5"

1000cc Canister

WA-RCAN10

For use with 1000cc disposable liner WA-CNLNR-1000

1500cc Canister

WA-RCAN15

For use with 1500cc disposable liner WA-CNLNR-1500

Canister with Wall Mount and ON-OFF Valve

Pre-attached bracket assembly with built-in ON-OFF valve. Has pre-attached tubing for connection to disposable liner. Wall to outer edge of canister is 8.5"

1000cc Canister

WA-RCAN10-VLV

For use with 1000cc disposable liner WA-CNLNR-1000

1500cc Canister

WA-RCAN15-VLV

For use with 1500cc disposable liner WA-CNLNR-1500

3000cc Canister

WA-RCAN30-VLV

For use with 3000cc disposable liner WA-CNLNR-3000

Canister with Extended Wall Mount and Regulator Connection

Used to mount regulator on bracket assembly. Comes with a female DISS. Has pre-attached tubing for connection to disposable liner. Wall to outer edge of canister is 13"

1000cc Canister

WA-RCAN10-DFW

For use with 1000cc disposable liner WA-CNLNR-1000

1500cc Canister

WA-RCAN15-DFW

For use with 1500cc disposable liner WA-CNLNR-1500

3000cc Canister

WA-RCAN30-DFW

For use with 3000cc disposable liner WA-CNLNR-3000

Canister with Direct to Regulator Connection

Connects reusable outer canister directly to vacuum regulator DISS where no wall mount is available. Wall to outer edge of canister is 8.5"

1000cc Canister

WA-RCAN10-VRDF

For use with 1000cc disposable liner WA-CNLNR-1000

1500cc Canister

WA-RCAN15-VRDF

For use with 1500cc disposable liner WA-CNLNR-1500

Disposable Liners (50/CS)

Disposable liners require a reusable outer canister. Blue lids are permanently attached to the flexible liner. Each flexible liner is shrink-wrapped and must be stretched to fit into the reusable outer canister.



WA-CNLNR-1000
1000cc Liner



WA-CNLNR-1500
1500cc Liner



WA-CNLNR-3000
3000cc Liner

Disposable Canisters (40/CS)

Disposable hard canister system. Rigid blue lid that snaps onto clear plastic disposable canister. Canister fits into reusable ring bracket with built-in flow valves.



WA-CAN-1200
1200cc Canister



WA-CAN-2000
2000cc Canister



WA-CAN-3000
3000cc Canister

Ring Brackets & Accessories

Ring Brackets – wall plates are required for mounting the following ring brackets

Ring Bracket

Reusable polycarbonate bracket used to support the canister.

WA-CNHL-1200

For use with 1200cc disposable canister WA-CAN-1200
Wall to outer edge of ring 9.5"



WA-CNHL-2000


For use with 2000cc & 3000cc disposable canister WA-CAN-2000 or -3000
Wall to outer edge of ring 10"

Ring Bracket with built-in ON-OFF Valve

Reusable polycarbonate bracket used to support the Canister. Comes with ON-OFF valve built into bracket. Has pre-attached tubing for connection to canister.

WA-CNHL-12-VLV


For use with 1200cc disposable canister WA-CAN-1200
Wall to outer edge of ring 7.75"



WA-CNHL-20-VLV

For use with 2000cc & 3000cc disposable canister WA-CAN-2000 or -3000
Wall to outer edge of ring 9.5"

Accessories




6700-0725-800
Plastic DISS Male with DISS Female Nut & Gland (10/CS)



WA-PLATE
Wall Plate




WA-TUBING
Bulk Connection Tubing 5/16" ID 100 ft Roll
Includes 10 Straight Tube Connectors



WA-CNMAN-2
Two-canister Manifold




VR-4STND30
30" Canister Stand



WA-CNMAN-3
Three-canister Manifold



VR-4STND30-DN
30" Vacuum Regulator Stand



WA-CNMAN-4
Four-canister Manifold