




# Vacuum Solutions for the Dairy Industry

# Vacuum Solutions for the Dairy Industry

#### LIQUID RING VACUUM PUMPS

Compact motor mounted pumps feature stainless steel impellers and mechanical seals.



\*Requires separate NEMA motor.



#### **TWO STAGE VACUUM PUMPS**

are ideal for deeper vacuum applications, such as whey evaporation. All models are fitted with mechanical seals and stainless steel impellers. Available as a bare pump or as an MB module, complete with tri-voltage motor, coupling, and guard, mounted on a formed base.

	27LC	27C	210C	215C	220C	225C
Motor HP	7.5	7.5	10	15	20	25
Displacement (CFM)	65	95	124	173	236	259
Connections	<b>1</b> ½"	11⁄2"	11⁄2"	2"	2"	2"

# Vacuum Solutions for the Dairy Industry

#### **ROTARY VANE VACUUM PUMPS**

Oil sealed, air cooled rotary vane pumps provide deep vacuum 29.9" Hg. (~2 torr) needed on packaging applications. All models feature durable tri-voltage motors. Optional liquid cooling kits are available for high heat environments.



	S3-N	S5L-N	S5-N	S7L-N	S7-N	S10-N	S12-N	S20-N	S25-N
Motor HP	3	5	5	7.5	7.5	10	10	15	25
Displacement (CFM)	44	70	118	130	164	192	211	305	470
Connections	11⁄4"	11⁄4"	2"	2"	2"	2"	2"	3"	3"



#### **CLAW VACUUM PUMPS**

Oil-less rotary claw vacuum pumps are well suited for medium vacuum applications such as tray forming or light packaging. They are equipped with tri-voltage motors and discharge silencers.

	C2	C3B	C5B	C7LB	C7B	C10B	C15B
Motor HP	2	3	5	7.5	7.5	10	15
Displacement (CFM)	40	70	112	165	212	275	350
Connections	1"	<b>1</b> ½"	<b>1</b> ½"	2"	2"	3"	3"

### SERVICE PARTS FOR SELECTORR® AND BUSCH® PUMPS



Typical service parts, such as filter and rebuild kits, are readily available from our stock. Most replacement items in Selectorr<sup>®</sup> rotary vane pumps also fit into Busch<sup>®</sup> vacuum pumps

#### **VACUUM FILTERS**



In-line "T" style filters are easy to install. Clear collection bucket allows for quick monitoring of material buildup. Available with polyester or paper elements.



Liquid separators protect the pump from liquids in the air stream. A 50 mesh stainless steel screen traps large particulates. Float ball blocks vacuum when bucket is full. Includes bottom 1/2" drain.

#### **MECHANICAL SEALS**

Versatile mechanical seals are applicable for most liquid ring vacuum pumps. A rubber friction ring prevents the seal from sliding on the shaft, eliminating shaft fretting. The seal can be rotated in either direction, as the spring merely provides axial load. Available from our stock in 28mm, 35mm, 38mm, 43mm, and 55mm sizes.





#### © 2019 Ohio Medical LLC. All Rights Reserved.

This document contains information that is proprietary and confidential to Ohio Medical LLC. Use of this information is under license from Ohio Medical LLC. Any use other than that authorized by Ohio Medical LLC is prohibited. Ohio Medical LLC, Selectorr, and the Ohio Medical LLC logo are registered trademarks and Squire-Cogswell and logo are trademarks of Ohio Medical LLC. Ohio Medical, Selectorr, and the Ohio Medical logo are registered trademarks and Squire-Cogswell and logo are trademarks of Ohio Medical. Busch is a registered trademark of Busch Consolidated, Inc.

Ohio Medical LLC 1111 Lakeside Drive Gurnee, IL 60031 USA 866.549.6446 | ohiomedicalparts.com 550008 (Rev. 3) 03/19