



ROTARY VANE VACUUM PUMPS

Oil sealed, air cooled rotary vane pumps provide deep vacuum (29.9" Hg. ~2 torr) needed on packaging applications. All models feature durable tri-voltage motors. Optional liquid cooling kits are available for high heat environments.



	S 3	S5L	S 5	S7L	S7	S10	S12	S20	S25
Motor HP	3	5	5	7.5	7.5	10	10	15	25
Displacement (CFM)	44	70	118	130	164	192	211	305	470
Connections	11/4"	11/4"	2"	2"	2"	2"	2"	3"	3"

SERVICE PARTS FOR SELECTORR® AND BUSCH® PUMPS



Exhaust filters are equipped with one way check valves, sealing rings, and heavy duty metallic ends. They are available individually or in filter kits, complete with oil filter and exhaust cover gasket.



Rebuild kits include vanes, seals, bearings, taper pins, and exhaust valve seat plates. Gasket kits are also offered for a complete pump rebuild.

LIQUID RING VACUUM PUMPS

compact motor mounted pumps feature stainless steel impellers and mechanical seals.



	SM30A	SM55A	SM75A	SM100A	SL150A*	SL200A*
Motor HP	3	5.5	7.5	10	15	20
Displacement (CFM)	35	74	86	126	205	270
Connections	1"	1½"	1½"	2½"	2½"	2½"

*Requires separate NEMA motor.



TWO STAGE VACUUM PUMPS

are ideal for deeper vacuum applications. All models are fitted with mechanical seals and stainless steel impellers. Available as a bare pump or as an MB module, complete with tri-voltage motor, coupling, and guard, mounted on a formed base. Also available in all stainless steel.

	27LC	27C	210C	215C	220C	225C
Motor HP	7.5	7.5	10	15	20	25
Displacement (CFM)	65	95	124	173	236	259
Connections	11/2"	1½"	1½"	2"	2"	2"



OIL-LESS CLAW VACUUM PUMPS

are well suited for medium vacuum applications such as tray forming or light packaging. All models feature tri-voltage motors and discharge silencers.

	C2	СЗВ	С5В	C7LB	С7В	C10B	C15B
Motor HP	2	3	5	7.5	7.5	10	15
Displacement (CFM)	40	70	112	165	212	275	350
Connections	1"	11/2"	1½"	2"	2"	3"	3"

VACUUM FILTERS



In-line "T" style filters are easy to install. Clear collection bucket allows for quick monitoring of material buildup. Available with polyester or paper elements.



Liquid separators protect the pump from liquids in the air stream. A 50 mesh stainless steel screen traps large particulates. Float ball blocks vacuum when bucket is full. Includes bottom 1/2" drain.

MECHANICAL SEALS

Versatile mechanical seals are applicable for most liquid ring vacuum pumps. A rubber friction ring prevents the seal from sliding on the shaft, eliminating shaft fretting. The seal can be rotated in either direction, as the spring merely provides axial load. Available from our stock in 28mm, 35mm, 38mm, 43mm, and 55mm sizes.



© 2019 Ohio Medical LLC. All Rights Reserved.

This document contains information that is proprietary and confidential to Ohio Medical LLC. Use of this information is under license from Ohio Medical LLC. Any use other than that authorized by Ohio Medical LLC is prohibited. Ohio Medical LLC, Selectorr, Busch, and the Ohio Medical LLC logo are registered trademarks and Squire-Cogswell and logo are trademarks of Ohio Medical LLC